
Mask Set Errata for Mask 0M29W

Introduction

This report applies to mask 0M29W for these products:

- MC9RS08KB12
- MC9RS08KB8
- MC9RS08KB4
- MC9RS08KB2

MCU device mask set identification

The mask set is identified by a 5-character code consisting of a version number, a letter, two numerical digits, and a letter, for example 0M29W. All standard devices are marked with a mask set number and a date code.

0001: Startup issue on the KB family MCUs when powering up from a residual voltage

Description: The device can enter an erroneous state and will not start code execution when powering up from a small residual supply voltage. The voltage range varies with temperature around 0.5 V. The probability of failure increases with the time during which the MCU is supplied with critical voltage prior to power up.

Workaround: To ensure proper device operation, the MCU should be powered down in less than 1 second. Ideally, the device should be powered up from 0 V. A power up time greater than 1 ms can contain the issue if a proper power down cannot be achieved.



How to Reach Us:

Home Page:

freescale.com

Web Support:

freescale.com/support

Information in this document is provided solely to enable system and software implementers to use Freescale products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document.

Freescale reserves the right to make changes without further notice to any products herein. Freescale makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. Freescale does not convey any license under its patent rights nor the rights of others. Freescale sells products pursuant to standard terms and conditions of sale, which can be found at the following address: freescale.com/SalesTermsandConditions.

Freescale, and the Freescale logo, are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. All other product or service names are the property of their respective owners.

© 2013 Freescale Semiconductor, Inc.

